

Introduction

This instruction shows how to install a ferrite bead onto field wiring for building system equipment. Use the photo below to loop field wiring through a ferrite bead. Place a tie wrap in the position indicated to secure bead in place. Tie wrap must pass through wire loop and around wires leaving bead to be secure.

Note: If shielded cable is used, then the shield and shield drain wire must not pass through the bead. See installation instructions or wiring diagrams for your equipment for specific wiring instructions. Neatly dress and secure all wiring. Adhere to all applicable electrical regulations.

